

QReplica 3.0

Sync. Replication

White Paper

July 2022

AC&NC / JetStor

www.acnc.com support@acnc.com sales@acnc.com 412.980.4534 5001 Baum Blvd., Ste 680 Pittsburgh, PA 15213

1. INTRODUCTION

QReplica 3.0 (Remote Replication) provides synchronous replication solutions. With QReplica 3.0 feature, DR (Disaster Recovery) can be achieved with simple and easy orchestration between JetStor platforms. In this document, synchronous replication concepts and detail procedures will be introduced for having best practice of DR mechanism with platform.

1.1. Start with Disaster Recovery

DR (Disaster Recovery) is about preventing total failure of mission critical business systems and to recover within minimum time and impact. Preventing data loss requires a continuous data protection method. This includes preparation for and recovery from events of human error, software and hardware failure, network down, internal or external power failure and all other events. To beat this challenge, IT managers must plan for redundancy of one or more backup systems at different locations. This involves constant or periodically data duplication to infrastructures at different sites to ensure business continuity from constant availability.

1.1.1. Understanding RPO and RTO

RPO (Recovery Point Objective) and RTO (Recovery Time Objective) are the two most important parameters in a disaster recovery. To achieve continuous data protection, you must understand these 2 key indicators that measure acceptable business risk. These goals can guide companies in choosing the best data backup plan.

- RPO (Recovery Point Objective): RPO refers to the maximum amount of data loss that the system can tolerate. It refers to the time point corresponding to the recovered data after the business is restored. The RPO depends on the update level of the data recovery. This update level can be the last day. The backup data can also be 1 hour ago data. This is related to the frequency of data backup. In order to improve RPO, the frequency of data backup must be increased. RPO is an indicator that reflects the integrity of data restored.
- RTO (Recovery Time Objective): RTO is the duration of time the system can tolerate service interruption. For example, if the service needs to be restored within half an hour after the occurrence, the RTO value is 30 minutes. The RTO is only the time period between the occurrence of a failure, from the moment when the system goes down and the application



stops, to the time when it is restored to support the operation. RTO is an indicator reflecting the timeliness of business recovery. It indicates the time required for business to recover from interruption to normal. The smaller the RTO value, the stronger the data recovery capability of the disaster recovery system. The IT administrators can deploy many disaster recovery systems. Obtain the smallest RTO, but it means investing a lot of money.



Figure 1-1 RPO and RTO Schematic Representation (from Wikipedia)

In Figure 1-1, the RPO indicator comes from before the failure occurs, and the RTO indicator comes from after the failure occurs. The smaller the value of the two is, the time interval can be effectively shortened from business transition period to normal.





stops, to the time when it is restored to support the operation. RTO is an indicator reflecting the timeliness of business recovery. It indicates the time required for business to recover from interruption to normal. The smaller the RTO value, the stronger the data recovery capability of the disaster recovery system. The IT administrators can deploy many disaster recovery systems. Obtain the smallest RTO, but it means investing a lot of money.



Figure 1-1 RPO and RTO Schematic Representation (from Wikipedia)

In Figure 1-1, the RPO indicator comes from before the failure occurs, and the RTO indicator comes from after the failure occurs. The smaller the value of the two is, the time interval can be effectively shortened from business transition period to normal.





not be committed to ensure consistency. In addition, write failures are sent back to its applications on the host. Then, application error handling will determine the next appropriate step for the pending transaction.



Figure 1-3 describes the write I/O pattern sequence with synchronous replication:

- 1. The application on the host sends a write request to the source volume.
- 2. The write I/O copies to the target volume.
- 3. The write I/O at the target is committed to the target volume.
- 4. The write commit at the target is confirmed back to the source.
- 5. The write I/O is committed to the source volume.
- 6. Finally, the write acknowledgement will be sent to the application on the host.



the system design is extremely complicated and the cost is very expensive. So it should avoid falling into the vicious circle of simply pursuing the improvement of the two indicators, and combining the actual situation, appropriately improving the two indicators according to local conditions is the right way.

1.4. Support Firmware Version

The following summarizes the firmware versions supported by QReplica 3.0, including synchronous replication.

- SANOS
 - FW 2.0.0 supports synchronous replication with license
 - FW 2.0.1 supports local to remote of synchronous replication
- XEVO
 - FW 2.1.0 supports synchronous replication with license
 - FW 2.1.1 supports local to remote of synchronous replication

MODEL	OS	SYNCHRONOUS REPLICATION
XCubeSAN Series	SANOS FW 2.0.1	License
XCubeFAS 2026 (XF2026)	XEVO 2.1.1	License
XCubeFAS 3126 (XF3126)	XEVO 2.1.1	License

Table 1-2 Support Firmware Version



2. THEORY OF REMOTE REPLICATION OPERATIONS

This chapter will introduce the theory of remote replication operations in detail. Multiple backup solutions give you more choices to protect your data. With XEVO's unique automatic replication feature, you can easily deploy any synchronous remote replication without configuration. Through local-to-remote, you can transfer your local backup to remote sites without redoing full copy again. This technology gives you multiple ways to protect your digital assets safely.



Figure 2-1 Remote Replication Diagram

2.1. Synchronous Replication

Synchronous replication is a block-level volume backup function through LAN or WAN. It is a timely replication function that can always synchronize source and target data. It uses iSCSI function to establish a replication connection. The replication task can use the full bandwidth of the assigned network port to allow the best backup speed.

We assume that the synchronization source port must be greater than or equal to 10 Gbps to ensure normal operation. However, the synchronization source port in the source storage is not limited to the dedicated one. In order to balance replication traffic, it is still recommended to separate the port of incoming data from the host and the synchronization source port to the target storage.







When a user creates a synchronous replication task, it will automatically copy all data from the source volume to the target at the beginning. This is also called **full replication**. At the same time, the source system will record a **fracture log** to maintain the block whether has been synchronized. The fracture log is a bitmap saved in the source storage to indicate which block of the source have been updated.





Figure 2-3 Fracture Log in Synchronous Replication

It is invoked when the target of a replication connection is lost for any reason and becomes out of sync. For example, when an incident such as a network interruption occurs, the source cannot replicate the data to the target, I/O from the host will still continue to be written to Source. The fracture log is kept update until the incident is resolved. The source will learn about the unsynchronized blocks and replicate them to the synchronized state.







Figure 2-3 Fracture Log in Synchronous Replication

It is invoked when the target of a replication connection is lost for any reason and becomes out of sync. For example, when an incident such as a network interruption occurs, the source cannot replicate the data to the target, I/O from the host will still continue to be written to Source. The fracture log is kept update until the incident is resolved. The source will learn about the unsynchronized blocks and replicate them to the synchronized state.





If a network error still occurs and the replication is blocked, the system will issue a warning every 20 seconds and enter the failed state after 60 seconds. Therefore, the task will be stopped. At this point, if you want to continue the task, you have to start it manually.

Another operation is that the user can manually stop the task until the user manually resumes the task, the situation is the same. If you are not sure whether the target has been touched, you can also perform a **full replication** first when restarting the task.

2.3. Auto Configuration

It does easily deploy the remote replication without doing configurations. In a protection group, you only need to log in a remote system through management port. The source system will send the configurations of volumes to the remote system. The remote system will generate the corresponding volumes for the source system.





The target system has to prepare at least 3 disk drives and the capacity of the target pool should be larger than the total capacity of all source volumes in the protection group.

Generally, auto replication operates in the following manner.

- 1. From source unit, login to the management port of the target unit.
- 2. Source unit will send the configurations of volumes which user want to back up to the target unit.
- 3. The target unit will generate the corresponding volumes for source unit
- 4. The source unit will start the replication task.

2.4. Traffic Shaping

The traffic shaping function can help reserve the necessary bandwidth for non-replication I/O operations. Eight shaping groups can be set. In each shaping group, peak and off-peak time slots are provided for different bandwidths.

2.5. MPIO in Remote Replication Task

In the remote replication scenario, MPIO (Multi-Path I/O) supports redundancy. Usually, the remote replication task runs on the master controller (usually CTRL 1) of the source unit. The data is replicated from the master controller of source unit to the target unit, and the target unit is set with the target IP address (usually also CTRL 1) when creating the remote replication task. The second path from the source unit can be added to the CTRL 2 of the target unit. The maximum MPIO in a remote replication task is 2 paths. The following is a remote replication MPIO diagram.



How Redundancy Is Used with Remote Replication



If CTRL 1 fails on the source unit, the replication connection will be taken over by CTRL 2 and the replication task will continue running.



Figure 2-8 Remote Replication Source Controller Fail Diagram

In another case, when CTRL 1 fails on the target unit, the replication connection will fail over to the second path from CTRL 1 of the source unit to CTRL 2 of the target unit.



2.6. MC/S in Remote Replication Task Path

MC/S (Multiple Connections per Session) is another feature in remote replication. If there are multiple iSCSI ports available on the source unit and they can be connected to other iSCSI ports on the target unit, you can add MC/S to increase the replication speed. The maximum MC/S for each task path is 4 connections.

2.7. Local Clone Transfers to Remote Replication

In order to handle full replication of large amounts of data, replication allows local cloning tasks to be converted into remote replication tasks. You can perform a local clone of the full copy first. Then, use the disk roaming function to physically transfer the disk drive containing the



cloned volume to the remote site. Finally, use the function of converting from a local clone task to a remote replication task.

When performing a replication task for the first time, full replication via LAN or WAN is always a problem. With limited network bandwidth, it may take days or weeks to copy data from the source to the target. We provide **local to remote** (local clone transfers to remote replication) method to help users shorten the time to execute a full copy.



Figure 2-10 Local Clone Transfers to Remote Replication Diagram

1 Step Local-to-Remote

Through local-to-remote, transfer your local backup to remote sites without having to redo the full copy. On the remote side, you only need to insert all disk drives without any configurations. And then complete the local-to-remote process.







INFORMATION

The **Auto Replication** and **1 Step Local-to-Remote** features are supported by XEVO only. It means that the source and target arrays are both running XEVO. In addition, The management ports and data ports of the source and target arrays must be connected to each other. Whether they are direct connections or through LAN switches.

Generally, local to remote operates in the following manner.



Figure 2-12 Local Clone Transfers to Remote Replication

3. Rebuild the replication connection.

2.8. Support Scenario

The replication scenarios supported by the models are summarized below. The XCubeSAN and XCubeFAS series can be the source and target of each other for remote replication through manual configuration. But only XEVO OS supports auto configuration, this feature is only available for XCubeFAS series. For the local clone to remote copy function, it is best that the source and target are the same model.



SOURCE	OS	MANUAL CONFIGURATION	AUTO CONFITURATION	LOCAL TO REMOTE
XCubeSAN Series	SANOS FW 2.0.1	XCubeSAN Series XF2026 XF3126	Х	XCubeSAN Series
XCubeFAS 2026 (XF2026)	XEVO 2.1.1	XCubeSAN Series XF2026 XF3126	XF2026 XF3126	XF2026
XCubeFAS 3126 (XF3126)	XEVO 2.1.1	XCubeSAN Series XF2026 XF3126	XF2026 XF3126	XF3126.

Table 2-1Support Scenario



3. CONFIGURE REMOTE REPLICATION

This chapter will discuss the remote replication feature which allows users to create synchronous replication tasks for block storage between supported systems. All configuration and management operations in this section will be demonstrated.

3.1. Prerequisites

This section describes remote replication prerequisites. First, list the parameters of remote replication. The maximum replication task quantity per volume is 1, and the maximum replication task quantity per system is 32 which including both synchronous replication tasks.

Table 3-1Synchronous Replication Parame	ters
ITEM	VALUE
Maximum remote replication task quantity per volume (Maximum remote replication pairs per source volume)	1
Maximum remote replication task quantity per system	32
Maximum iSCSI multi-path quantity in a remote replication task	2
Maximum iSCSI multiple connection quantity per remote replication task path	4

Preliminary Preparation of Creating a Remote Replication Task



The following takes the creation of a remote replication task from the source volume to the target volume as an example. Suppose we defined the name and IP address in the example.



Figure 3-1 Example of Creating a Synchronous Replication Task

Site A (Source Unit) Configuration:

- Controller 1, Onboard LAN 1 IP Address: 10.10.1.1
- Controller 1, Onboard LAN 2 IP Address: 10.10.1.2
- Controller 2, Onboard LAN 1 IP Address: 10.10.1.3
- Controller 2, Onboard LAN 2 IP Address: 10.10.1.4
- Source Volume Name: Src_Vol_01, Src_Vol_02

Site B (Target Unit) Configuration:

- Controller 1, Onboard LAN 1 IP Address: 10.10.1.101
- Controller 1, Onboard LAN 2 IP Address: 10.10.1.102
- Controller 2, Onboard LAN 1 IP Address: 10.10.1.103
- Controller 2, Onboard LAN 2 IP Address: 10.10.1.104
- Target Volume: Name: Tgt_Vol_01, Tgt_Vol_02

3.2. License

The synchronous replication license must be purchased to enable the feature. There is also a 30-day free trial license for evaluation. Although the setting method is different from XEVO and SANOS, the following sections describe the configuration separately.



3.2.1. Enable Synchronous Replication License

The synchronous replication function is optional. Before using it, you have to enable synchronous replication license. Select the **System** tab and the **Maintenance** subtab, and then click the **Licenses** pane to allow users to active licenses.

🗐 Licenses		~
Synchronous Replicatior	1	
Status	Disable	
Download Request License f	le and send to your local sales to get a License Key. Request License	
Update File	file path	
Trial License		
Status	Disable	
Click the Request License bu in to enable the 30-day trial p official production.	tton to download a file and use it to request a trial license key. When you get the trial license key beriod. You can try the advanced features until it expires. We DO NOT recommend using trial feat	r file, put it tures in
Request License		
Update File	file path 🖸 Apply	
	the Trial License Agreement	
	ne marticense Agreement.	

Figure 3-2 Enable Synchronous Replication License

Click the **Request License** button to download the file and send to your local sales to obtain a License Key. After getting the license key, click the icon to select it, and then click the **Apply** button to enable. Each license key is unique and dedicated to a specific system. If the license is active, the status will show as **Enable**. After enabling the license, the system must reboot manually to take effect.

3.3. Configure Synchronous Replication

This section describes how to create synchronous replication and its related functions. We provide two methods to setup the tasks, auto and manual configuration. With XEVO's unique automatic replication feature, you can easily deploy any remote replication without configuration. Manual configuration is the traditional way to complete the settings step by step.



3.3.1. Auto Configuration

Here is an example of creating a synchronous replication task with auto configuration.

Prepare in Site B (Target Unit)

The target unit has at least 3 free disks without any pool configuration, and the total capacity is greater than or equal to the source volumes. In addition, the data ports in the target unit are connected to the source unit and can be pinged.



TIP

The auto configuration can run in the same firmware version of the source and target units.

Configure Replication Plan-Remote in Site A (Source Unit)

1. Click the + icon in the **Protection Groups** pane to pop up a wizard.



Create Protection Group			
Volume Group	Protection P	lan	Finish
Group Name ProtectionGroup	_001		
Select Volumes			
	2/2 items		0 item
Src_Vol_01			
Src_Vol_02			
		Not Found	
	_		
Create Volume			
			Cancel Next

Figure 3-3 Synchronous Replication – Auto Configuration Step 1

- 2. Select source volumes, and then click the **button** to move them from the left side to the right side.
- 3. Click the **Next** button to continue.



•
Cancel

Figure 3-5 Synchronous Replication – Auto Configuration Step 3

- 6. Select the **Mode** as **Synchronous** and select the **Deployment Method** as **Auto**.
- 7. Click the **Next** button to continue.



INFORMATION

Synchronous replication requires a license. Please contact your local sales to obtain a license. If there is no license, the synchronization option is not visible.

Remote Replication Plan			
iource Port	Auto ~	٢	
Remote Syste	m		
ernote IP address	192.168.1.234		
Joser na me	admin		
bourses			



- 8. If necessary, select the **Source Port** or leave it as Auto.
- 9. Login to the management port of the target unit. Enter the **Remote IP address** of the target management port.
- 10. Enter the **Username** and **Password** of the target administrator account.
- 11. Click the Apply button to finish the Replication Plan Remote configuration.



/olume Group		Protection Plan	Finish
apshot Plan			
	Disable		Enable
plication Plan			
Local	Disable		Enable
	Disable		Disable Edit

Figure 3-7 Synchronous Replication – Auto Configuration Step 5



12. Back to main screen of the wizard. Click the **Apply** button to create a replication task.

Create Protectio	on Group		
Volume Group		Protection Plan	Finish
Results			
Overall Status	 Success 		
Details			
Connect Volume	Success		
Enable Snapshot Plan	Success		
Enable Replication Plan	Success		
			Clos

Figure 3-8 Synchronous Replication – Auto Configuration Step 6

13. There is a result page. Click the **Close** button to close the wizard.



3.3.2. Manual Configuration

Here is an example of creating a synchronous replication task with manual configuration.

Prepare Backup Volumes in Site B (Target Unit)

1. Create a pool and multiple volumes with capacity greater than or equal to the source volumes.

Figure 3-9 Synchronous Replication – Auto Configuration Step 7

14. Done. A protection group with synchronous replication task has been created.



Click the icon beside each volume name to list the drop down option
 Properties option to change the volume properties.





3. Change the Volume Type to Backup Volume, and then click the Apply button to take effect.

Pool	Tgt_Po	ol_01 🌣					
Capacity	0.02 T	В / 0.72 ТВ			2% Used		
	Health Status Controller	• Good Online CTRL 1			Actual Space 744 GB Available Space 722 GB Provisioning Type Thick Provisioning		
	Disk Gr	oups			~		
0)))	Volume	es.			^		
					2 items 🚺 📋 🕂		
	!	Volume Name	Capacity	LUN	Volume Type		
	•	Tgt_Vol_01 🌣	11.00 GB	-	Backup Volume		
	•	Tgt_Vol_02 🜣	11.00 GB	-	Backup Volume		
4					< 1 / 1 >		

Figure 3-11 Synchronous Replication – Manual Configuration Step 2

- 4. Here are the target volumes.
- 5. Create a host group with the target volumes in the **Hosts** tab.



Host Group	HostGro	up_001 🌣				
Protocol		IQN				
Volumes		2				
Hosts		1				
Enabled Da	ta Ports	4				
CTRL	Target Name		Alias	Slot 1	Slot 2	Onboard
1	iqn.2004-08.cd	om.qsan:xcubefas:dev1.ctr1 🌼	-			**
2	iqn.2004-08.co	om.qsan:xcubefas:dev1.ctr2 🔅	-			**

G	6 H	ost	Profile					~
will	C	onr	nected Volumes					^
							2 items 次	+
		ļ	Volume Name	Capacity	LUN	Volume Type		
		•	Tgt_Vol_01	11.00 GB	0	BACKUP		
		•	Tgt_Vol_02	11.00 GB	1	BACKUP		
						< [1 / 1	>

Figure 3-12 Synchronous Replication – Manual Configuration Step 3

6. Here is the host group for target volumes.

Configure Replication Plan-Remote in Site A (Source Unit)

7. Click the + icon in the **Protection Groups** pane to pop up a wizard.



Create Protection Grou	р		
Volume Group	Protection Plan	1	Finish
Group Name ProtectionGrou	up_001		
Select Volumes			
	2/2 items		0 item
Src_Vol_01			
Src_Vol_02			
		Not Found	
Create Volume			
		С	ancel Next

Figure 3-13 Synchronous Replication – Manual Configuration Step 4

- 8. Select source volumes, and then click the button to move them from the left side to the right side.
- 9. Click the **Next** button to continue.



Create Protec	tion Group		
• Volume Group		Protection Plan	Finish
Snapshot Plan			
Snapshot	🖈 Disable		Enable
Replication Pla	n		
Local	🗈 Disable		Enable
Remote	🗈 Disable		Enable
			Cancel Back Apply

Figure 3-14 Synchronous Replication – Manual Configuration Step 5

10. Click the **Enable** text link in the **Remote** pane to enable the **Replication Plan - Remote**.



Remote Replication Plan	
	●
Mode	
Asynchronous	
• Synchronous	
Deployment Method	
Auto	
Manual	
	Cancel

Figure 3-15 Synchronous Replication – Manual Configuration Step 6

- 11. Select the Mode as Synchronous and select the Deployment Method as Manual.
- 12. Click the **Next** button to continue.



INFORMATION

Synchronous replication requires a license. Please contact your local sales to obtain a license. If there is no license, the synchronization option is not visible.

Remote Repl	ication Plan	
		••
Source Port	Auto v 2	
Remote IP address	10.10.1.101	
		Cancel Back Next

Figure 3-16 Synchronous Replication – Manual Configuration Step 7

13. If necessary, select the **Source Port** or leave it as Auto.



- 14. Enter the **Remote IP address** of the target data port.
- 15. Click the **Next** button to continue.



TIP

The source port for synchronous must be greater than or equal to 10 Gbps. If you do not want to assign a fixed port, please leave the setting of **Source Port** as **Auto**. The system will try to connect to the target IP address automatically.

Remote R	eplication	Plan		••
Target and	Authentica	tion		Auto Pairing Clear All
Volume	Capacity	Target Name	Target Volume	LUN
Src_Vol_01	10.00 GB	iqn.2004-08.com.qsa V	11GB Tgt_Vol_01	✓ 0
Src_Vol_02	10.00 GB	iqn.2004-08.com.qsa ∨	11GB Tgt_Vol_02	 ✓ 1
4				•
				< 1 / 1 >
				Cancel Back Apply

Figure 3-17 Synchronous Replication – Manual Configuration Step 8

- 16. Click the **Auto Pairing** button to automatically pair the backup volumes. If they are not what you want, manually select the **Target Name** and **Target Volume**.
- 17. If the target encrypts with CHAP, click the icon next to the Target Name, it will pop up a dialog box to enter the CHAP information.
- 18. Click the Apply button to finish the Replication Plan Remote configuration.



Create Protec	tion Group		
• Volume Group		Protection Plan	✓ Finish
Snapshot Plan			
Snapshot	🖹 Disable		Enable
Replication Pla	n		
Local	🗄 Disable		Enable
Remote	🖹 Disable		Disable Edit
			Cancel Back Apply

Figure 3-18 Synchronous Replication – Manual Configuration Step 9

19. Back to main screen of the wizard. Click the **Apply** button to create a replication task.



Create Protectio	on Group		
• Volume Group		Protection Plan	Finish
Results			
Overall Status	Success		
Connect Volume Enable Snapshot Plan Enable Replication Plan	 Success Success Success 		
			Close

Figure 3-19 Synchronous Replication – Manual Configuration Step 10

20. There is a result page. Click the **Close** button to close the wizard.



Protection	Group P	ProtectionG	oup_00)1 ≎					
Protec	tion V	/olumes	on Tasks						
							2 items Replicat	te Now	
		Volume Name	Mode	Capacity	Target Name	Target LUN	Completed	Speed	Status
+		Src_Vol_01 🌣	Sync	10GB	iqn.2004-08.com.qsan:xcubefas:dev1.ctr2	0	0	0 MB/s	synced
+		Src_Vol_02 🌼	Sync	10GB	iqn.2004-08.com.qsan:xcubefas:dev1.ctr2	1	0	0 MB/s	synced
		Figure	3-20 S	ynchron	ous Replication – Manual Co	nfiguratic	< on Step 11	1 /	1 >

21. Done. A protection group with synchronous replication task has been created.



TIP

When the synchronous replication task has been created, the full replication will start automatically.

3.3.3. Replication Options

The options are available in this tab.

Stop Replication Task

Click the icon of the volume to stop the replication task.



Start Replication Task

Select a volume, and then click the icon to replicate the volume immediately. It will pop up dialog box asking if you want to resume the task or perform a full replication. After selecting, click the **OK** button.



Figure 3-21 Synchronous Replication – Start Dialog

The option **Resume** will replicate the out-of-sync part. If you can not sure whether the target has been touched, you can also perform a **Full Replication**. The progress bar displays the current status.

Ungroup Volume from Protection Group

To ungroup the volume from the protection group, check one or multiple volume names, and then click the button.

Delete Protection Group

To delete the protection group, click the icon beside the protection group name to list the drop down options. Click the **Delete** option; it will pop up dialog box to confirm. Click the **Delete** button to delete the protection group.

3.3.4. Enable Multipath and Add Connections

Click the icon next to the volume name to list the drop down options. Click the **Connection Properties** option to enable multipath and add connections for the replication task.

Connection Properties							
Protection Group Volume Enable MultiPat	ProtectionGroup_001 Src_Vol_01 h	I					
						1 items	
No.		Source Port		Target IP Address		Status	
1	Add Connection	Auto	~	10.10.1.101	C	Connected	
					Cance	Apply	

Figure 3-22 Synchronous Replication – Connection Properties

Enable Multipath

1. Check the **Enable MultiPath** checkbox to enable multipath for the replication task.

Connection Properties								
Protection Group Volume ✔ Enable MultiPa	ProtectionGroup_(Src_Vol_01 th	001						
No.		Source Port		Target IP Address		2 items		
	Add Connection	Auto	×	10.10.1.101	C	Connected		
2	Add Connection	Auto	~	10.10.1.102		Connected		

Figure 3-23 Synchronous Replication – Enable Multipath

- 2. If necessary, select the **Source Port** or leave it as Auto.
- 3. Enter the **Target IP address** of the target data port.
- 4. Click the **Apply** button to enable.

Add Connections

1. Click the Add Connection button to add another connection.



Connection Properties								
Protection Volume Enable	Group MultiPat	ProtectionGroup_0 Src_Vol_01 h	01					
	No.		Source Port		Target IP Address		2 items 👘 Status	
	1	Add Connection	Auto	~	10.10.1.101	C	Connected	
	1		Auto	~	10.10.1.102		Connected	
						Canc	el Apply	

Figure 3-24 Synchronous Replication – Add Connection

- 2. If necessary, select the **Source Port** or leave it as Auto.
- 3. Enter the Target IP address of the target data port.
- 4. Click the **Apply** button to add.

3.3.5. Switch Local Clone to Remote Replication

Through local-to-remote, you can transfer local backup to remote sites without redoing full copy. You can plug and play when local-to-remote without any configurations.

Configure Replication Plan-Local in Site A (Source Unit)

1. Click the + icon in the **Protection Groups** pane to pop up a wizard.



Create Protec	tion Group					
• Volume Group		Pr	otectio	n Plan		Finish
Group Name	ProtectionGroup_001					
Select Volumes	6					
		2/2 items				0 item
Src_Vol_01						
Src_Vol_02						
			<			
			>		Not Found	
Create Volume						
						Cancel Next

Figure 3-25 Synchronous Replication – Local to Remote Step 1

- 2. Select source volumes, and then click the **button** to move them from the left side to the right side.
- 3. Click the **Next** button to continue.



Create Protec	tion Group		
• Volume Group		Protection Plan	Finish
Snapshot Plan			
Snapshot	🖹 Disable		Enable
Replication Pla	n		
Local	🖹 Disable		Enable
Remote	🗈 Disable		Enable
			Cancel Back Apply

Figure 3-26 Synchronous Replication – Local to Remote Step 2

4. Click the Enable text link in the Local pane to enable the Replication Plan - Local.



Local R	eplication Plan			
Selected	Target Pool			
• Tgt_Poo	bl_01	1.46 TB		
Create Pool				
Schedule	9			
● Once				
Repeat				
🖲 Daily				
🔿 Weekl	y 🛛 🗹 Mon 🗹 Tue 🗹 Wed 🗹			
 Month 	ly 1 ~			
🔿 Repea	t every 30 minutes V			
Start Time	00 ~ : 00 ~			
End Time				
			Cancel	Apply

Figure 3-27 Synchronous Replication – Local to Remote Step 3

- 5. Select a target pool. If none can be selected, click the **Create Pool** link to create a pool.
- 6. Click the **Apply** button to create a local clone task. And then click the **Close** button to close the wizard.





7. After the local clone is complete, click the icon next to the protection group name to list the drop down options. And then click the **Protection Plan Setting** option.



Protection Plan Setting							
Snapshot Plan							
Snapshot	🖄 Disable	Enable					
Replication Pla	1						
✔ € Local	☑ Once Disable Switch to Remote	Edit					
Remote	🖺 Disable	Enable					
		Close					

Figure 3-29 Synchronous Replication – Local to Remote Step 5

8. Click the Switch to Remote text to configure the replication plan.

Switch to Remote	
Mode	
Asynchronous	
Synchronous	
	Cancel Apply

Figure 3-30 Synchronous Replication – Local to Remote Step 6

- 9. Select the Mode as Synchronous.
- 10. Click the **Apply** button and then click the **Close** button to close the wizard.
- 11. Deactivate the target pool.
- 12. Remove all disk drives of the target pool and deliver them to the Site B (Target Unit).



Prepare Backup Volumes in Site B (Target Unit)

- 13. Insert all disk drives of the target pool and activate them.
- 14. Create a host group to include the target volumes.

Configure Replication Plan-Remote in Site A (Source Unit)

15. Select the source volume of the protection group.



Protection Volumes

Snapshot Tasks		s Replica	Replication Tasks								
									2 items	Reco	nnect 🕇
		Volume Nam e	Mod e	The Last T ask	Capaci ty	Target Na me	Target L UN	Created	Completed	Speed	Status
+		Src_Vol_ 🌼 01		-	11GB	-	-	Invalid D ate	Retry	undefined M B/s	Switch fai Ied
+		Src_Vol_ 🌼 02		-	10GB	-	-	Invalid D ate	Retry	undefined M B/s	Switch fai Ied
										< 1	/ 1 →

Figure 3-31 Synchronous Replication – Local to Remote Step 7

16. Click the **Reconnect** button to reconnect to the target volume. It will pop up a wizard.



Reconnect	
	•
Deployment Method	
Auto	
O Manual	
	Cancel Next
	Cancer

Figure 3-32 Synchronous Replication – Local to Remote Step 8

17. Select the **Deployment Method** as **Auto** or **Manual**.

- 18. Click the **Next** button to continue.
- 19. The following takes **Auto** as an example, if you choose **Manual**, please refer to steps 13 to 18 in the <u>3.3.2 Manual Configuration</u> section.

Reconnect		
Source Port	Auto ~	
Remote Syste	m	
Remote IP address	192.168.1.234	
Username	admin	
Password	••••	

Figure 3-33 Synchronous Replication – Local to Remote Step 9

- 20. If necessary, select the Source Port or leave it as Auto.
- 21. Login to the management port of the target unit. Enter the **Remote IP address** of the target management port.
- 22. Enter the Username and Password of the target administrator account.
- 23. Click the **Apply** button to finish the **Reconnect** configuration.
- 24. Click the **Close** button to close the wizard.



Protectio	n Group P	rotectionGr	oup_00	01 🌣					
Prote	ction V	Snapshot Plan	nn Tasks		Replication Plan-Local	Replicat	ion Plan-Remote		
							2 items Replica	te Now	
		Volume Name	Mode	Capacity	Target Name	Target LUN	Completed	Speed	Status
+		Src_Vol_01 🌼	Sync	10GB	iqn.2004-08.com.qsan:xcubefas:dev1.ctr2	0	0	0 MB/s	synced
+		Src_Vol_02 🌼	Sync	10GB	iqn.2004-08.com.qsan:xcubefas:dev1.ctr2	1	0	0 MB/s	synced
								1 /	1 >

Figure 3-34 Synchronous Replication – Local to Remote Step 10

25. Done. A protection group with synchronous replication task has been reconnected.

4. Use Cases

This chapter will introduce some use cases for remote replications.

4.1. Remote Replication Topologies

Remote replication supports multiple topologies to suit various disaster recovery configurations. They are one.directional, bi-directional, one-to-many, many-to-one, and many-to-many. Both the source volume and destination volume in a replication connection are exclusive to the pair. Either one can NOT be served as the source or destination volume of a different replication connection. Below are the supported topologies.

One-Directional



Figure 4-1 One-Directional Remote Replication

A Source Volume S in Site A is replicating to a Target Volume T in Site B. This is the most basic remote replication topology.

Bi-Directional



Figure 4-2 Bi-Directional Remote Replication



Each system in a two system topology acts as a replication target for the others production data. A Source Volume (S1 in Site A is replicating to a Target Volume T 1 in Site B. And a Source Volume S2 i n Site B is replicating to a Target Volume T2 i n Site A.

One-to-Many



Figure 4-3 One-to-Many Remote Replication

A single source system replicates different storage resources to multiple target systems. A Source Volume S1 i n Site A is replicating to a Target Volume T1 i n Site B. At the same time, a Source Volume S2 i n Site A is replicating to a Target Volume T 2 in Site C. So does S3 in Site A to T3 in Site D.



Figure 4-4 Many-to One Remote Replication



©2023 ACNC/JetStor All rights reserved. www.acnc.com

Many-to-One

Multiple source systems replicate to a single target system. A Source Volume S1 in Site B is replicating to a Target Volume T1 in Site A. At the same time, a Source Volume S2 in Site C is replicating to a Target Volume T2 in Site A. So does S3 in Site D to T3 in Site A.



Many-to-Many

Figure 4-5 Many-to Many Remote Replication

Combination with bi-Directional, one-to-many, and many-to-one, remote replication also supports Many-to-Many topology. Multiple source systems replicate to multiple target systems. A Source Volume S1 in Site A is replicating to a Target Volume T1 in Site B. At the same time, a Source Volume S 2 in Site B is replicating to a Target Volume T2 in Site A. And does S3 to T3, S4 to T4, S8 to T8.

TIP Note that for each individual replication session in the topology, all supported topologies have a one-to-one configuration. or example, you cannot set a volume as a replication source and target at the same time. Similarly, a volume cannot be the source of synchronous replication at the same time.



4.2. Synchronous Replication Failover

Initially, you can set up normal usage of synchronous replication. The I/O sequence bl ue lines will go from Host to Source, and then Source to Target.



Figure 4-6 Synchronous Replication Failover

If an accident occurs and the Source is disconnected, you can manually failover to the target and let the IO sequence oran ge lines g o to the Target. At the same time, you can also switch Source and Target roles.

4.3. Synchronous Replication + C2F Solution

As we know, a volume with WT (rit e-through) capability writes IO to drives. This ensures that data is definitely written to the drives. In contrast, a volume with B (ri te-back) capability temporarily writes IO to cache and writes it to the drive in batches as planned. Generally, a volume with write-back capability has better performance than a write-through volume.

If you use write-back parameter to set the volume, there are still risks. h en the power is off unexpectedly, the data in the cache will disappear. C2 C ache to las h solution can prevent this. Both Source and Target have to add the C2 modules.



The best practice of volume write-back plus C2 solution can balance performance and data integrity.

5. CONCLUSION

This document discusses the various replication solutions. Configuring a data protection solution helps prevent unexpected situations, such as data loss. e provide local and remote data protection solutions to help easily recover in the event of a disaster. By using both synchronous replication solutions, data protection can be configured to meet the needs of enterprises.

Synchronous replication usually writes data to source unit and replicas at the same time. In this way, the primary copy and the replica are always in sync. In the event of a disaster, synchronous replication can provide maximum protection and ensure zero data loss.



6. **APPENDIX**

6.1. Apply To

Synchronous replication requires a **License** to enable the feature. We also provide a 30-day free **Trial License** for evaluation. The synchronous replication function is applicable to the following models.

• XEVO firmware 2.1.0 and later

6.2. Reference

Software Manuals

<u>XEVO Software Manual</u>

